

PRESS RELEASE

Upgrade of electromagnetic flow meters product line

Mass Flow ONLINE B.V. proudly presents you an upgrade of the entire **MAG-VIEW™ P-series**. The upgrade mainly relates to an improved and optimized *flow range* and *accuracy*. Moreover the *signal output starting point* has been improved.

The MAG-VIEW™ P-series operates on the magnetic inductive principle and is therefore suitable for electrically conductive liquids with a minimum conductivity of 50 $\mu\text{S/cm}$. The frequency of the pulse output signal or signal current of the analog output (optional) is proportional to the flow. The flow meters feature fast response, low pressure drop and a weatherproof (IP65) enclosure. The upgraded models measure in a flow range from 0.5-30 l/min, 1-60 l/min and 5-250 l/min with a measurement accuracy of $\pm 1.5\%$ RD, $\pm 0.3\%$ FS.

Referring to the industrial sector of low flow liquid measurement, the new MAG-VIEW P-series enables you to increase the productivity with existing machines, increase the production quality and adjust production processes to new demands in the future.



The new MAG-VIEW™ P-series

The MAG-VIEW™ P-series can be easily ordered from stock at Mass Flow ONLINE B.V. 24 hours a day, 7 days a week on www.massflow-online.com. From this web shop, competitively priced, high quality products with excellent delivery time can be ordered. Your on-line order will be shipped within two working days.

For more information, please visit www.massflow-online.com



selling online high quality mass flow
measurement and control products

contact us at: sales@massflow-online.com or
visit our website www.MASSFLOW-ONLINE.com